



- Align pattern or grain direction of laminate to match backsplash; cut around cover with a hobby knife, leaving 1/4" on all sides



- Peel off backing



- Apply to front of cover



- Cut away small squares at each corner



- Fold edges over cover



- Cut away switch/outlet holes with a hobby knife



- Your cover is ready to be installed